

USER'S MANUAL

Notice to Customer

To keep always in the optimum performance your love motorcycle should be submitted for regular checking. We suggest that after the first 300km or running your motorcycle has to be examined at your local service center and thereafter once again every 1000km.

Preface

Thanks for your choice of **our motorcycle** It is meticulously designed and accurately manufactured with advanced technology and modern equipment so as to offer you a safe and comfortable feeling for drive, thus bringing you more convenience during your daily-life and study.




Please read this manual carefully before your initial drive and understand all details in it. It will help you to know what is the good method of maintenance and service, and how to operate your vehicle in order to have less trouble and long service life.

We sincerely wish you have a good trip on your motorcycle.

Note:

Because of our continuous improvement, perhaps there is a little difference between this manual and your motorcycle. If your have any questions about it, please contact with distributor.

LIST

I.VARIOUS PARTS OPERATION	1		
A. INSTRUMENT PANEL			
1. speedometer			
2. Accumulated distance meter			
3. Fuel meter			
4. High beam indicator			
5. Turn signal indicator			
B. MAIN SWITCH			
1. OFF			
2. ON			
3. LOCK	2		
C.STARTER SWITCH BUTTON			
D.HEADLIGHT SWITCH			
1. 			
2. 			
3. 	3		
E.DIMMER SWITCH			
1. HI			
		2..LO	
		F.HORN SWITCH BUTTON	
		G.TURN SIGNAL SWITCH	
		1.L	
		2.R	
		I.MULTI-PURPOSE CASE	4
		J STEERING HANDLE LOCK	
		1.Locking	
		2.Unlocking	
		II.HOW TO START ENGINE	5
		A. START ENGINE WITH ELECTRICITY	
		B. START ENGINE WITH KICK STARTER PEDAL	6
		III.HOW TO RIDE MOTORCYCLE	
		A.START RIDING	7
		B.SPEED ADJUSTMENT	
		1.Turn	

LIST

2.Return		
C.PROPER RIDING MAY LENGTHEN THE LIFE OF MOTORCYCLE		
D.DO NOT BRAKE OR TURN AROUND ABRUPTLY	8	
E.RIDE CAREFULLY ESPECIALLY IN RAIN		
IV.HOW TO STOP		
A.NEAR PARKING PLACE		
B.MOTORCYCLE STOPS COMPLELETELY		
C.CHOOSE A PLAIN PLACE	9	
V.INSPECTION BEFORE RIDING		
A.OIL		
1.Oil inspection/replenishment		
B.GASOLINE	10	
1.Gasoline inspection/replenishment		
C.STEERING HANDLE INSPECTION		
D.BRAKE INSPECTION	11	
1.Drum brake series		
2.Disk brake series		
E.STOPLIGHT INSPECTION		
F.TURN SIGNAL LIGHT INSPECTION		
G.TIRE INSPECTION	12	
H.SHOCK ABSORBER INSPECTION		
I.HEADLIGHT AND TAILLIGHT INSPECTION		
J.HORN INSPECTION		
K.SPEEDOMETER INSPECTION		
L.BACK MIRROR INSPECTION		
VI.PERIODICAL INSPECTION		
A.OIL AND FILTER	13	
1.Air cleaner replacement		
2.Oil change and filter cleaning		
3.How to change oil and clean filter		
B.GEAR OIL CHANGE	14	

LIST

I.How to change gear oil	
C.REPLENISHMENT OF BRAKE OIL (DISK BRAKE)	15
D.SPARK PLUG INSPECTION	
1.Cleaning	
2.Adjustment	
3.Recommended spark plug	
E.BATTERY AND ELECTROLYTE INSPECTION	17
F.FUSE REPLACEMENT	
VII.WHEN ENGINE CAN NOT START	18
VIII.SPECIFICATION(1)	19
SPECIFICATION(2)	20

I. VARIOUS PARTS OPERATION

A. INSTRUMENT PANEL:

1. Speedometer:

- Forward speed is based on 1km per hour:

2. Accumulated distance meter:

- Total forward distance is indicated by km. The black number with white background indicates 100m unit.

3. Fuel meter:

- It indicates the fuel volume in the fuel tank. (Turn on main switch first)
- If the needle points at red section, it indicates that the effective residue fuel is about 1.5 liters. Fill with gasoline as soon as possible.
- Please insert your key into the release hole, or it can not show exactly.

4. High beam indicator:

- Turn on headlight switch at night. If dimmer switch is at "HI", the indicator will light

and it indicates high beam.

5. Turn signal indicator:

- Turn signal indicator will blink if turn signal switch in operation.

B. MAIN SWITCH



1. OFF:

- The electric power of engine is turned off and engine stop.
- You can take off the key.

2. ON:

- The electric power of engine is connected

And you can start

- You cannot take off the key.

3. LOCK:

- The steering handling is locked.
You can take off the key.

NOTICE:

- After locking, turn steering handle gently to make sure it is locked up.
- Do not park at the place retarding traffic.

C. STARTER SWITCH BUTTON:




- Press down starter switch button to use electric

starter.

NOTICE:

- After engine start release the button at once.
- Do not use the button more than 4 seconds each time
- When engine in operation, do not press down the button to avoid bad effect on engine.

D. HEADLIGHT SWITCH:



1. " "

- Headlight, instrument light and taillight Extinguish at the same time.

2. "DC"



- Position light and instrument light light on at the same time.

3. "O"



- Headlight, instrument light and taillight light on at the same time.

E. DIMMER SWITCH:

1. 

High Beam

2. 

Low Beam:

- To light far away, change over the switch to "HI". While a vehicle approaching in front or riding in downtown, if keep high beam, it will affect the vision of



others. Change over the switch to "LO"

- If high beam, the high beam indicator on instrument panel will light.

F. HORN SWITCH BUTTON:



- Turn on main switch and press down horn switch button to sound horn.

G. TURN SIGNAL SWITCH

1. L:

- Use when turn left.

2. R:

- Use when turn right. Use turn signal lights while



turning or changing lanes. Turn on the switch and turn signal lights will blink

- If use turn signal lights, the turn signal indicator on instrument panel in the same direction blinks at the same time.

NOTICE:

- Turn signal lights cannot stop automatically. Return it to the original position after use, or it will affect traffic safety.
- If main switch is at "OFF", turn signal lights cannot operate.

L.MULTI-PURPOSE CASE:



- NOTICE:

- Do not load stuff more than 3kg.
- It is very hot in the case. Do not deposit any article which can be easily burned.
- If use high pressured water to wash, it may easily be wet.

J.STEERING HANDLE LOCK:



To prevent stealing, lock steering handle while parking.

1. Locking:

Turn steering handle to full left and turn key counter-clock-wise to lock.

2. Unlocking:

- Turn the key clock-wise to unlock

NOTICE:

- After locking, turn steering handle gently to make sure it is locked off.
- Do not park at the place retarding traffic.

II. HOW TO START ENGINE:

A. START ENGINE WITH ELECTRICITY:

- Turn main switch to "ON".



- When the key is turn to "ON", check horn and turn signal light if work well.
- Start engine with electric starter. Do not turn throttle grip, just press down starter switch button to start engine.



NOTICE:

- After engine start, leave the finger away from the button at once.
- If engine is in operation, do not press down starter switch button, or it will have bad effect on engine.
- Do not use starter more than 4 seconds each time.

B. START ENGINE WITH KICK STARTER PEDAL:



- If motorcycle has not been used for a long time, it may be uneasy to start, Turn throttle grip by 1/8-1/4 round and start engine again.
- If cold start, warm up engine for 2-3 minutes.

NOTICE:

- After using kick starter pedal, pull it back to Original position.

- The carbon dioxide exhausted from engine is harmful. Do not start engine where is narrow or ventilation is not good.
- Do not turn throttle grip, step kick starter pedal Down quickly with strength to start engine.

III.HOW TO RIDE MOTORCYCLE:

- Release rear brake lever.
- Add gasoline slowly with throttle grip and then motorcycle will move forward smoothly.



NOTICE:

- Do not add much gasoline suddenly with throttle grip to prevent motorcycle out rust unexpectedly .

A. START RIDING:

- Turn on turn signal lights before move.
- Make sure it is safe behind before moving forward.

B. SPEED ADJUSTMENT:

- Speed can be adjusted under the control of throttle grip.



1. Turn:

- Speed becomes fast.
- Add gasoline slowly.

2. Return:

- Speed becomes slow.
- Do it swiftly when return to original position.

C. PROPER RIDING MAY LENGTHEN THE LIFE OF MOTORCYCLE:

- If the motorcycle is within 3,000km, keep speed below 60km/hr.
- Do not increase speed abruptly.
- Do not operate engine at high r.p.m. without load.

NOTICE:

- Apply one side brake only may cause motorcycle slip up.
- Apply front brake and rear brake at the same time:

After return throttle grip to original close position, apply front and rear brakes at the same time for braking.

- While braking, pull front brake lever and step down rear brake pedal slowly in the beginning, then tightly. It is the best way to brake.

D. DO NOT BRAKE OR TURN AROUND ABRUPTLY:

- Brake or turn around abruptly may cause slip-up and fall-down. It is very dangerous.

E. RIDE CAREFULLY ESPECIALLY IN RAIN:

- The road surface in rain is different from which in sunshine. The braking distance becomes longer in rain. Therefore, reduce speed and

brake earlier.

- While descending, return throttle grip to original close position and brake intermittently to keep speed slow.

IV. HOW TO STOP:

A. NEAR PARKING PLACE:

- Turn on the signal lights earlier. Take care of the vehicles behind and park motorcycle slowly.
- Return throttle grip to original close position. Apply front and rear brakes earlier and then stoplight will light to warn the vehicles behind.

B. MOTORCYCLE STOPS COMPLETELY:

- Return turn signal switch to original position and turn main switch to " OFF "

NOTICE:



- It turn off main switch and pull out the key during riding, the electric system will become out of function and it may cause accident. Do it while parking only.

C. CHOOSE A PLAIN PLACE:

- Choose a plain place of retarding traffic and raise up the main stand. Motorcycle is easy to fall down at a place not plain.
- Grasp left handle with left hand to make motorcycle straight. Hold side handrail below seat with right hand. Step down main stand to raise up with right foot and pull back motorcycle with right hand with strength.
- To prevent stealing, lock the steering handle when park and take out the key.



VI.INSPECTION BEFORE RIDING:

- Get used to check up before riding.
- For safety and preventing trouble or accident, pre-check up is necessary.
- If not so difficult or troublesome, make sure to check up before riding.If any abnormality, deliver the motorcycle to the distributor or service center for inspection and repair.


NOTICE:

- If check oil volume or replace oil soon after stop, beware of burning.

A. GASOLINE:

1. Oil inspection/Replenishment:
Oil volume check:
 - Raise up main stand.
 - Take off oil level gauge and clean up.

- Insert the gauge (do not lock in)
- Take off the gauge and check oil volume. If oil level near lower level, replenish till upper level.
- There are many kinds of oil. Improper choice may cause trouble easily. We recommend you the brand of SAE 10W-30(SIGMA) for your engine.
- If motorcycle is inclined or just stopped, it is impossible to check oil level properly.



B. GASOLINE:

1. Gasoline inspection/replenishment:

- When the pointer of fuel meter is close to red section, the effective residual gasoline is about 1.5 liters.

NOTICE:

- Turn off engine when replenishing gasoline.
- Take off the key from main switch and insert it into fuel tank cap. Turn the key clock-wise and open fuel tank cap.
- Keep gasoline level under away from the height panel of fuel tank while replenishing. If gasoline level is too high, it is easy to leak out.

C. STEERING HANDLE INSPECTION:

- Check steering handle up and down, forward and backward, left and right if any looseness.
- Check if it is too tight. Check



if any hitting sound, if any abnormality, deliver the motorcycle to the

- The distributor or service center for inspection and repair.

D. BRAKE INSPECTION:

1. Drum brake series:

- The free play or brake lever or pedal should be properly adjusted. The free play is about 1-2cm normally.
- Free play means the distance between loose and tight positions of brake lever or pedal.

REAR WHEEL BRAKE ADJUSTMENT:

NOTICE:

- After brake adjustment, match the concavity of adjustment, match the concavity of adjusting nut with axle pin to prevent the danger resulting from the change of free lay during riding.
- Ride motorcycle in a short distance to make

sure the effect of front and rear brakes.

2. Disk brake series:

● BRAKE OIL INSPECTION:"

- Normal fluid level is between "UPPER" and "LOWER".
- When the fluid level is near the lower level mark, check brake pads
- If brake pads are in good condition, it usually mean some where are leaking brake oil.

E. STOPLIGHT INSPECTION:

- Turn main switch to "ON"
- Operate front and rear brakes one by one to make sure if stoplight lights.
- Check stoplight if



any dirt or damage.

F. TURN SIGNAL LIGHT INSPECTION:

- Turn main switch to "ON":
- Operate turn signal switch to make sure if turn signal lights and turn signal indicators blink.
- Check turn signal lights if any dirt to damage.

G. TIRE INSPECTION:

- Check tire pressure if normal.
- Check if there is any metal trash or gravel in the grooves of tires.
- If there is any crack or wearing exceeding the limit, replace the tire at once.
- While check the tire pressure, tire must be in cooling state.
- The main reason of going crack, unstable

handle and abnormal abrasion are caused by the abnormal tire pressure.

- Do not overload to avoid tire explosion. If there is Normal Tyre Pressure in it:

Normal tyre pressure	
Front wheel	196kpa
Rear wheel	221kpa

H. SHOCK ABSORBER INSPECTION:

- Add weight on the handle and seat, swing motorcycle up and down and check the front and rear shock absorbers if work well.

I. HEADLIGHT AND TAILLIGHT INSPECTION

- Turn main switch to "ON". Operate headlight switch to check if headlight and taillight light. Check the lights if any dirt or damage.

I. HORN INSPECTION:

Turn main switch to "ON", and press down horn switch button to check if the horn sounds.:

J. SPEEDOMETER INSPECTION:

Check if speedometer works.

K. BACK MIRROR INSPECTION:

Sit on the seat to make sure the position behind and check back mirror if any dirt or damage.

VII.PERIODICAL INSPECTION:

- For safe and comfortable riding, be sure to make periodical inspection.
- Our motorcycle distributors and service centers provide after service, maintenance and repair for you.
- If the motorcycle has not been used for a long time, it is also necessary to make periodical inspection.
- Be sure to make inspection and maintenance in 1 month or in 300km after buying the new motorcycle.

A. OIL AND FILTER:

1. Air cleaner replacement:

- remove left side cover.
- remove attaching screws and air cleaner cover.

NOTICE:

- Dirt on air cleaner is the main reason to lower engine power and waste fuel.
- If air cleaner is not placed properly, dirt will be sucked into cylinder to cause wearing, lowering engine power and shortening engine life.
- Do not let air cleaner soak in water while washing motorcycle, or it will have bad effect in starting.

2. Oil change and filter cleaning:

- When to change oil and clean filter.
- Change oil and clean filter at first 300km and every 1,000km after.

Capacity of Oil
Disassembly: 0.9liter
General Change: 0.75liter

3. How to change oil and clean filter:


- Remove oil level gauge, Remove drain plug to make all the oil flow out. If engine is warm, it is easier to make oil flow out.
- Remove oil filter cap and take off spring and filter screen. Use high-pressured air to clean.
- Install oil filter and drain plug.
- Fill with new oil 0.9 liter. Check with oil level gauge. (Do not screw in the gauge when check)
- Tighten up oil level gauge
- After engine becomes warm, stop running for 10-20seconds. Recheck oil volume.

NOTICE:

- Please use SAE 10W-30(SIGMA) oil.
- Riding in the following conditions will make oil become inferior and please change it earlier.
 - ◇ Always ride on gravel road.
 - ◇ Always ride for short distance.
 - ◇ Always run with neutral gear.
 - ◇ Ride at the area with cold weather.
- When replenish oil, do not exceed the upper level.
- When change oil, if engine is still hot, beware of burning.

B. GEAR OIL CHANGE:

- Change gear oil at first 300km and each 3000km or per six month.
- Please use No10, or gear oil of the brand GY..
- Capacity of gear oil 110c.c.



1. How to change gear oil:

- Remove drain plug to make all the oil flow out. If engine is warm, it is easier to make oil flow out.
- Install drain plug.
- Fill with new gear oil 110c.c.
- Tighten up tiller nut definitely to prevent lead out.

NOTICE:

- Riding in the following conditions will make oil quality become inferior and please change it earlier.
 - ◇ Always ride on gravel road.
 - ◇ Ride for a long distance.
 - ◇ Ride at the area with wet weather.

C. REPLENISHMENT OF BRAKE OIL: (DISK BRAKE)

- Turning the bike handle until the brake oil level in storage tank become horizontal.
- Remove the tank cover and seal.
- Replenish the specific brake oil up to the above of the mark "LOWER", then screw up the cover screws.
Brake oil: DOT-3.
- Assemble the seal, tank cover and upper handle cover.

D. SPARK PLUG INSPECTION: NOTICE:

- Use only the specific brake oil. Otherwise, the rubber seal will be distorted and lead to oil leakage. The function will not work.
- Do not mix both specific and non-specific oils together, otherwise, it will cause a chemical reaction and lead to brake failure.
- Do not let the water penetrate into the main cylinder, otherwise, the boiling point will be lowered and lead to be choked
- The painting surface and plastic parts will be corroded by the brake oil. In case of spilt, please be sure to clean promptly.
- Please find out the problem with our distributor or service center if the standard level of brake oil is not able to be reached.

NOTICE

- Too large gap, deposit and electrode erosion will result in incomplete spark.

1. Cleaning:

- It is the best way to clean with the cleaner of spark plug.
- Use wire brush if no cleaner.


2. Adjustment:

Normally the side electrode gap is 0.6-0.7mm. (as shown)

3. Recommended spark plug:

CR7HSA(NGK),U22FS-U(ND)

- Do not use the spark plug not recommended.
- Engine is still very hot after engine stops. Beware of burning.
- Turn spark plug finger tight, then tighten with



spark plug wrench.

E. BATTERY AND ELECTROLYTE INSPECTION:

- This series use M/F Battery so you do not have to inspect electrolyte.

NOTICE:

- Absolutely do not open the lid of battery.
- Battery may produce flammable air. Take care of fire when install or remove.
- If not used for a long time, battery may self-discharge. To prevent the leak of electricity, recharge battery first and place it at a cool place. If battery is kept on the motorcycle, disconnect negative terminal.

F. FUSE REPLACEMENT:

REMOVE:

- Turn out the cap of fuse case and take out the fuse.
- If fuse connection is not good, the fuse will overheat and breakdown.

INSTALL:

- Install the fuse into fuse case and fasten the cap.
- Try to pull the fuse after install. If loose, the fuse will overheat and breakdown.

NOTICE

- Do not use any fuse whose specification is different from assigned. It is the main reason for wiring burning.
- If cannot find out the reason, deliver the motorcycle to the distributor or service center for inspection and repair.
- Do not use high pressured water to wash around the side cover.

VIII.WHEN ENGINE CAN NOT START:

- Check effective gasoline.
- Check the way of start engine.
- Check other parts if there any problem
- When you motorcycle is out of order, please send it to the distributor or service team, we are sure you will be satisfied.

Specification (1)

Model Items	125T-6	125T-2	125T-9	125T-8	125T-3	125T-7	125T-10	
Overall dimension (mm) LxWxL	1940x745x1140	1735x690x1050	1780x665x1100	1880x665x1135	1700x690x1095	1790x700x1120	1935x665x1110	
Wheel base (mm)	1348	1275	1220	1255	1215	1500	1345	
Ground clearance (mm)	127	105	95	115	95	130	105	
Net weight (kg)	110	94	110	111	110	110	120	
Max.driving speed (km/h)	80.0	80.0	80.0	80.0	80.0	90.0	80.0	
Max.Loading capacity (kg)	150	150	150	150	154	150	150	
Tire specifications	front	3.50-10	3.50-10	3.50-10	3.50-10	3.50-10	130/60-13	3.50-10
	rear	3.50-10	3.50-10	3.50-10	3.50-10	3.50-10	130/60-13	3.50-10
Braking mode	front	Disk	Drum	Disk	Drum	Disk	Disk	Disk
	rear	drum	drum	drum	drum	drum	Drum	drum
Type of starter	Electric, kick	Electric, kick	Electric, kick	Electric, kick	Electric, kick	Electric, kick	Electric, kick	
Ignition type	CDI	CDI	CDI	CDI	CDI	CDI	CDI	
Cylinder volume	124. 65	124. 65	124. 65	124. 65	124. 65	124. 65	124. 65	
Compression ratio	92:1	92:1	92:1	92:1	92:1	92:1	92:1	
Rate power	5.0/7500	5.0/7500	5.0/7500	5.0/7500	5.0/7500	5.0/7500	5.0/7500	
Max.torque	7.2/7500	7.2/7500	7.2/7500	7.2/7500	7.2/7500	7.2/7500	7.2/7500	
Bore X Stroke	52.4x57.8	52.4x57.8	52.4x57.8	52.4x57.8	52.4x57.8	52.4x57.8	52.4x57.8	

Specification(2)

Model		100T-10	100T-9	100T-19	50QT-10	50QT-13	150T-C	150T-1
Overall dimension (mm) LxWxL		1880x665x1155	1735x690x1050	1790x690x1095	1700x620x1030	1780x665x1105	2110X750X1330	1940X720X1140
Wheel base (mm)		1255	1215	1215	1220	1220	1500	1375
Ground clearance (mm)		105	95	90	95	100	115	100
Net weight (kg)		101	93	105	65	105	133	118
Max.driving speed (km/h)		73.0	73.0	73.0	50.0	73.0	90.0	80.0
Max.Loading capacity (kg)		150	150	140	80	140	150	150
Tire specifications	front	3.50-10	3.50-10	3.50-10	3.50-10	3.50-10	110/90-12	110/90-10
	rear	3.50-10	3.50-10	3.50-10	3.50-10	3.50-10	110/90-12	110/90-10
Braking mode	front	Disk	Drum	Disk	Drum	Disk	Disk	Disk
	reat	Disk	drum	drum	drum	Drum	drum	drum
Type of starter		Electric, kick	Electric, kick	Electric, kick	Electric, kick	Electric, kick	Electric, kick	Electric, kick
Ignition type		CDI	CDI	CDI	CDI	CDI	CDI	CDI
Cylinder volumn(ml)		102.10	102.10	102.10	49.58	102.10	147.5	147.5
Compression ratio		92:1	92:1	92:1	10:1	92:1	10:1	10:1
Rate power(nw/r/min)		4.00/7500	4.00/7500	4.00/7500	1.90/7500	4.00/7500	5.0/7500	5.0/7500
Max.torque(nw/r/min)		6.00/6000	6.0/6000	6.0/6000	2.80/6000	6.0/6000	7.2/7500	7.2/7500
Bore X Stroke(mm)		49.5x57.8	49.5x57.8	49.5x57.8	39x41.5	49.5x57.8	57x57.8	57X57.8

