





PBZ125-3图表



序号Sr.No	件号 Part No.	英文名称 English Description	中文名称 Chinese Description	数量 Quantity
1	PBZ125-3-A-1	MUFFLER	消音器	1
2	PBZ125-3-A-2	Brake pedal	刹车踏杆	1

3	PBZ125-3-A-3	Brake lever	刹车拉杆	1
4	PBZ125-3-A-4	Brake lever spring	刹车拉杆弹簧	1
5	PBZ125-3-A-5	Brake spring	刹车弹簧	1
6	PBZ125-3-A-6	Rear brake spring	后刹弹簧	1
7	PBZ125-3-A-7	Muffler washer	消音器垫圈	1




序号Sr.No	件号	英文名称	中文名称	数量
	Part No.	English Description	Chinese Description	Quantity
1	PBZ125-3-B-1	Left handlebar	左方向把手	1
2	PBZ125-3-B-2	Right handlebar	右方向把手	1
3	PBZ125-3-B-3	Lfet hand grip	左胶套	1
4	PBZ125-3-B-4	Throttle grip	油门胶套	1

5	PBZ125-3-B-5	Left control panel	左开关	1
6	PBZ125-3-B-6	Right control panel	右开关	1
7	PBZ125-3-B-7	Cable throttle	油门线	1
8	PBZ125-3-B-8	Carburetor	化油器	1
9	PBZ125-3-B-9	Steering head	上联板	1
10	PBZ125-3-B-10	Handle bar seat	方向把座	1
11	PBZ125-3-B-11	Handlebar lever lock	方向把锁紧手柄	2
12	PBZ125-3-B-12	Spring	弹簧	2




序号Sr.No	件号 Part No.	英文名称 English Description	中文名称 Chinese Description	数量 Quantity
---------	----------------	-----------------------------	-----------------------------	----------------

1	PBZ125-3-C-1	Footrest bracket	前脚踏支架	1
2	PBZ125-3-C-2	Left foot skin	脚踏皮左	1
3	PBZ125-3-C-3	Right foot skin	脚踏皮右	1
4	PBZ125-3-C-4	Side stand	单撑	1
5	PBZ125-3-C-5	Side stand bolts	单撑螺栓	1
6	PBZ125-3-C-6	Side stand spring	单撑弹簧	1
7	PBZ125-3-C-7	Engine shaft 1	发动机轴1	1
8	PBZ125-3-C-8	Engine shaft 2	发动机轴2	1




序号Sr.No	件号 Part No.	英文名称 English Description	中文名称 Chinese Description	数量 Quantity
---------	----------------	-----------------------------	-----------------------------	----------------

1	PBZ125-3-D-1	Engine	发动机	1
2	PBZ125-3-D-2	Engine cover	发动机边盖	1
3	PBZ125-3-D-3	Starting lever	启动杆	1
4	PBZ125-3-D-4	Shift lever	变档杆	1
5	PBZ125-3-D-5	Intake pipe	进气管	1
6	PBZ125-3-D-6	Intake pipe bolt	进气管螺栓	2
7	PBZ125-3-D-7	Bakelite mat 1	胶木垫1	1
8	PBZ125-3-D-8	Bakelite mat 2	胶木垫2	1
9	PBZ125-3-D-9	Engine gasket	发动机垫片	1



序号Sr.No	件号	英文名称	中文名称	数量
	Part No.	English Description	Chinese Description	Quantity

1	PBZ125-3-E-1	Seat	坐垫	1
2	PBZ125-3-E-2	Rear shock	后减震	2
3	PBZ125-3-E-3	Seat mounting shaft	坐垫安装轴	1



序号Sr.No	件号 Part No.	英文名称 English Description	中文名称 Chinese Description	数量 Quantity
1	PBZ125-3-F-1	FRAME	车架	1




序号Sr.No	件号 Part No.	英文名称 English Description	中文名称 Chinese Description	数量 Quantity
1	PBZ125-3-G-1	Front shock LH	前左减震器	1
2	PBZ125-3-G-2	Front shock RH	前右减震器	1
3	PBZ125-3-G-3	Front disc brake	前碟刹	1
4	PBZ125-3-G-4	Front axle	前轮轴	1
5	PBZ125-3-G-5	Front axle bushing	前轮轴衬套	1
6	PBZ125-3-G-6	Speed tooth	转速齿	1
7	PBZ125-3-G-7	Reflect mirror	边缘反射镜	2
8	PBZ125-3-G-8	Disc brake line clamp up	碟刹管线夹上	1
9	PBZ125-3-G-9	Disc brake line clamp down	碟刹管线夹下	1
10	PBZ125-3-G-10	Steering stem	下联板组件	1

11	PBZ125-3-G-11	Slotted nut	开槽螺母	1
12	PBZ125-3-G-12	shield	护罩	1
13	PBZ125-3-G-13	Flat washer	平垫圈	1
14	PBZ125-3-G-14	Head nut	封头螺母	1
15	PBZ125-3-G-15	Steel bowl	钢碗	4




序号Sr.No	件号	英文名称	中文名称	数量
	Part No.	English Description	Chinese Description	Quantity
1	PBZ125-3-H-1	Rear fender	后挡泥板	1
2	PBZ125-3-H-2	Front fender	前挡泥板	1
3	PBZ125-3-H-3	Side cover	车边盖	1
4	PBZ125-3-H-4	Rubber pad of front rear fender	前后挡泥板橡胶垫	4


6	PBZ125-3-H-6	Fuel tank skin	油箱皮	2
7	PBZ125-3-H-7	Front rubber pad of rear fender	后挡泥板前橡胶垫	2



序号Sr.No	件号	英文名称	中文名称	数量
	Part No.	English Description	Chinese Description	Quantity
1	PBZ125-3-I-1	Front tire	前轮胎	1
2	PBZ125-3-I-2	Front inner tire	前内胎	1
3	PBZ125-3-I-3	Rim 1	轮毂1	1
4	PBZ125-3-I-4	Rim 2	轮毂2	1
5	PBZ125-3-I-5	Drum, front hub	前制动鼓	1
6	PBZ125-3-I-6	Front brake disc	前碟刹盘	1



序号Sr.No	件号	英文名称	中文名称	数量
	Part No.	English Description	Chinese Description	Quantity
1	PBZ125-3-J-1	Rear tire	后外胎	1
2	PBZ125-3-J-2	Rear inner tire	后内胎	1
3	PBZ125-3-J-3	Rim 1	轮毂1	1
4	PBZ125-3-J-4	Rim 2	轮毂2	1
5	PBZ125-3-J-5	Rear sprocket	链轮	1
6	PBZ125-3-J-6	Drum, rear hub	后制动鼓	1



序号Sr.No	件号 Part No.	英文名称 English Description	中文名称 Chinese Description	数量 Quantity
1	PBZ125-3-K-1	Fuel tank	油箱	1
2	PBZ125-3-K-2	Hose	油管	1
3	PBZ125-3-K-3	Fuel tank switch	油箱开关	1
4	PBZ125-3-K-4	Cushion front	前安装座	2
5	PBZ125-3-K-5	Bushing	衬套	1
6	PBZ125-3-K-6	Rear cushion up	后安装座上座	1
7	PBZ125-3-K-7	Rear cushion down	后安装座下座	1
8	PBZ125-3-K-8	Bushing	衬套	1




序号Sr.No	件号	英文名称	中文名称	数量
	Part No.	English Description	Chinese Description	Quantity
1	ZH-SR-L-1	Wire harness	导线束总	1
2	ZH-SR-L-2	Battery bracket	电瓶支架	1
3	ZH-SR-L-3	Horn	喇叭	1
4	ZH-SR-L-4	Lock set	套锁	1
5	ZH-SR-L-5	Headlight	前大灯	1
6	ZH-SR-L-6	Ignition coil	高压泵	1
7	ZH-SR-L-7	Starter relay	继电器	1
8	ZH-SR-L-8	CDI	点火器	1
9	ZH-SR-L-9	Flasher	闪光器	1
10	ZH-SR-L-10	Rear brake switch	后刹开关	1

11	ZH-SR-L-11	Regulator	稳压器	1
12	ZH-SR-L-12	Air filter	空滤	1
13	ZH-SR-L-13	Air filter clamp	空滤卡箍	1
14	ZH-SR-L-14	Rear mirrors	后视镜	2




序号Sr.No	件号 Part No.	英文名称 English Description	中文名称 Chinese Description	数量 Quantity
1	PBZ125-3-M-1	Rear shelf	后货架	1
2	PBZ125-3-M-2	Tool set	工具总成	1
3	PBZ125-3-M-3	Tool box	工具箱	1
4	PBZ125-3-M-4	Tool box cover	工具箱盖	1
5	PBZ125-3-M-5	Tool box mounting washer	工具箱安装垫圈	1

6	PBZ125-3-M-6	Tool box cover snap	工具箱盖卡扣	1
7	PBZ125-3-M-7	Rear reflector	后反射镜片	1
8	PBZ125-3-M-8	Tool box lifting set	工具箱吊装组件	1
9	PBZ125-3-M-9	Tail light bracket	尾灯托板架	1
10	PBZ125-3-M-10	Tail light bracket set	尾灯支架组件	1
11	PBZ125-3-M-11	Tail light	尾灯(总成)	1
12	PBZ125-3-M-12	Right turning light	后右转向灯总成	1
13	PBZ125-3-M-13	Left turning light	后左转向灯总成	1



序号Sr.No	件号 Part No.	英文名称 English Description	中文名称 Chinese Description	数量 Quantity
1	PBZ125-3-N-1	Headlight cover	前大灯壳	1

2	PBZ125-3-N-2	Dashboard	仪表支架	1
3	PBZ125-3-N-3	Speedometer	仪表	1
4	PBZ125-3-N-4	Mileage line	里程线	1
5	PBZ125-3-N-5	Headlight bracket left	大灯支架左	1
6	PBZ125-3-N-6	Headlight bracket right	大灯支架右	1
7	PBZ125-3-N-7	Headlight bracket rubber pad	大灯支架缓冲皮	2
8	PBZ125-3-N-8	Headlight bracket base	大灯支架底座	2
9	PBZ125-3-N-9	Left rear turning light	后左转向灯	1
10	PBZ125-3-N-10	Right rear turning light	后右转向灯	1
11	PBZ125-3-N-11	Indicator light	指示灯	1
12	PBZ125-3-N-12	Rubber pad	橡胶垫	1
13	PBZ125-3-N-13	Speedometer spring	仪表弹簧	1
14	PBZ125-3-N-14	Neutral indicator light	空档指示灯	1



序号Sr.No	件号 Part No.	英文名称 English Description	中文名称 Chinese Description	数量 Quantity
1	PBZ125-3-O-1	Rear flat fork	后平叉	1
2	PBZ125-3-O-2	Rear flat fork bushing	后平叉衬套	2
3	PBZ125-3-O-3	Rear flat fork axle	后平叉轴	1
4	PBZ125-3-O-4	Battery band	电瓶攀带	1
5	PBZ125-3-O-5	Relay support	继电器支架	1
6	PBZ125-3-O-6	Filter support	过滤器支架	1
7	PBZ125-3-O-7	Chain cover	链罩	1
8	PBZ125-3-O-8	Chain	链条	1
9	PBZ125-3-O-9	Rear wheel axle	后轮轴	1
10	PBZ125-3-O-10	Rear wheel bushing	后轮衬套	1

11	PBZ125-3-O-11	Chain adjuster	调链器	2
12	PBZ125-3-O-12	Front fender support	前泥板支架	1
13	PBZ125-3-O-13	Mileage line support	里程线支架	1