

	ID	Part No.	Description
	1	SY125-A-1	DOUBLE OIL PIPE
	1-1	SY125-A-1-1	OIL SPRING
	2	SY125-A-2	FLAT PAD GB97.1-85
	3	SY125-A-3	FUEL PIPE BUCKLE
	4	SY125-A-4	HEXAGON FLANGE SELF-LOCKING NUTS-GB6187-86
	5	SY125-A-5	EXTERNAL HEXAGON BIG HEAD FLANGE BOLTS GB5789
	6	SY125-A-6	FUEL PIPE BUCKLE
	7	SY125-A-7	OIL TANK SWITCH
	8	SY125-A-8	OIL TANK
	9	SY125-A-9	SEAT
	10	SY125-A-10	HEXAGON FLANGE TOOTHED NUT GB6177-86
	11	SY125-A-11	OIL FILTER
12	SY125-A-12	INNER HEXAGON SOCKET HEAD SCREW GB70-85	

	ID	Part No.	Description
	1	SY125-B-1	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
	2	SY125-B-2	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
	3	SY125-B-3	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
	4	SY125-B-4	FLAT BUSHING
	5	SY125-B-5	HEXAGON FLANGE SELF-LOCKING NUTS GB6187-86
	6	SY125-B-6	CARBURETOR
	7	SY125-B-7	HEXAGON FLANGE TOOTHED NUT GB6177-86
	8	SY125-B-8	PLASTIC AIR FILTER ASSEMBLY
	9	SY125-B-9	ENGINE
	9-1	SY125-B-9-1	INTAKE PIPE

	ID	Part No.	Description
	1	SY125-C-1	MUFFLER
	2	SY125-C-2	HEXAGON CAP NUTS GB923
	3	SY125-C-3	MUFFLER COPPER RING
	4	SY125-C-4	FLAT PAD GB97.1-85
	5	SY125-C-5	FLAT PAD GB93-87
	6	SY125-C-6	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787

	ID	Part No.	Description
	1	SY125-D-1	INNER HEXAGON SOCKET HEAD SCREW GB70-85
	2	SY125-D-2	UPPER PRESSURE BLOCK
	3	SY125-D-3	FLAT BUSHING
	4	SY125-D-4	HEXAGON FLANGE SELF-LOCKING NUTS GB6187-86
	5	SY125-D-5	LOWER PRESSURE BLOCK
	6	SY125-D-6	COLUMN FIXING CLAMP
	7	SY125-D-7	FLAT BUSHING
	8	SY125-D-8	CLIP
	9	SY125-D-9	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
	10	SY125-D-10	HEXAGON FLANGE SELF-LOCKING NUTS GB6187-86
	11	SY125-D-11	SPLIT PIN
	12	SY125-D-12	SLOTTED NUT
	13	SY125-D-13	FLAT PAD GB97.1-85
	14	SY125-D-14	STEERING COLUMN
	15	SY125-D-15	FRAME PLUG

	ID	Part No.	Description
--	----	----------	-------------


	ID	Part No.	Description
	1	SY125-E-1	FRONT BUMPER BRACKET
	2	SY125-E-2	ENGINE HANGER
	3	SY125-E-3	FRAME ASSEMBLY
	4	SY125-E-4	BUTTER TIP CAP
	5	SY125-E-5	BUTTER NOZZLE STRAIGHT HEAD
	6	SY125-E-6	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
	8	SY125-E-8	HEXAGON FLANGE SELF-LOCKING NUTS GB6187-86
	9	SY125-E-9	FRAME PLUG

	ID	Part No.	Description
	1	SY125-F-1	LOWER ROCKER ARM LEFT
	2	SY125-F-2	LOWER ROCKER ARM RIGHT
	3	SY125-F-3	DUST CAP
	4	SY125-F-4	ROCKER ARM STEP SLEEVE
	5	SY125-F-5	FLAT BUSHING
	6	SY125-F-6	STEERING SHIFT
	7	SY125-F-7	ROCKER ARM ADJUSTABLE BALL HEAD
	8	SY125-F-8	HEXAGON FLANGE SELF-LOCKING NUTS GB6187-86
	9	SY125-F-9	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
	10	SY125-F-10	LEFT KNUCKLE
	11	SY125-F-11	RIGHT KNUCKLE
	12	SY125-F-12	SLOTTED NUT
	13	SY125-F-13	SPRING WASHER
	14	SY125-F-14	FLAT PAD GB97.1-85
	15	SY125-F-15	SPLIT PIN
	16	SY125-F-16	UPPER ROCKER ARM
	17	SY125-F-17	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
	18	SY125-F-18	UPPER ROCKER ARM LINED PIPE
	19	SY125-F-19	SLOTTED NUT
	20	SY125-F-20	SPRING WASHER
	21	SY125-F-21	FLAT PAD GB97.1-85
	22	SY125-F-22	SLOTTED NUT
	23	SY125-F-23	SPRING WASHER
	24	SY125-F-24	FLAT PAD GB97.1-85
	25	SY125-F-25	BUTTER NOZZLE STRAIGHT HEAD
	26	SY125-F-26	BUTTER TIP CAP


	ID	Part No.	Description
	1	SY125-G-1	REAR SWING ARM (black)
		SY125-G-1-1	REAR SWING ARM (grey)
	2	SY125-G-2	REAR AXLE SLEEVE
	3	SY125-G-3	BALL BEARING
	4	SY125-G-4	SWING ARM LINED PIPE
	5	SY125-G-5	HEXAGON FLANGE SELF-LOCKING NUTS GB6187-86
	6	SY125-G-6	HEXAGON FLANGE AXLE
	7	SY125-G-7	REAR BRIDGE SEAT
	8	SY125-G-8	REAR BRIDGE LINED PIPE
	9	SY125-G-9	BALL BEARING
	10	SY125-G-10	OIL SEAL
	11	SY125-G-11	JACK
	12	SY125-G-12	HEXAGON OPPOSITE SIDE NUT
	13	SY125-G-13	HEXAGON FLANGE SELF-LOCKING NUTS GB6187-86
	14	SY125-G-14	EXTERNAL HEXAGON BIG HEAD FLANGE BOLTS
	15	SY125-G-15	FLAT PAD GB97.1-85
	16	SY125-G-16	SPRING WASHER
	17	SY125-G-17	BUTTER NOZZLE STRAIGHT HEAD
	18	SY125-G-18	BUTTER TIP CAP
	19	SY125-G-19	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
20	SY125-G-20	FLAT BUSHING	

ID	Part No.	Description
21	SY125-G-21	TENSIONING WHEEL
22	SY125-G-22	


ID	Part No.	Description
1	SY125-H-1	REAR AXLE
2	SY125-H-2	EXTERNAL HEXAGON BIG HEAD FLANGE BOLTS
3	SY125-H-3	LOWER SPROCKET & DISC BRAKE COVER
4	SY125-H-4	SPROCKET
5	SY125-H-5	REAR SPROCKET FLANGE
6	SY125-H-6	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
7	SY125-H-7	DISC BRAKE PLATE FLANGE
8	SY125-H-8	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
9	SY125-H-9	REAR DISC BRAKE PLATE
10	SY125-H-10	UPPER CHANIN COVER
11	SY125-H-11	CHAIN
12	SY125-H-12	EXTERNAL HEXAGON BIG HEAD FLANGE BOLTS
13	SY125-H-13	HEXAGON OPPOSITE SIDE NUT
14	SY125-H-14	SPLIT PIN
15	SY125-H-15	SLOTTED NUT
16	SY125-H-16	FLAT PAD GB97.1-85
17	SY125-H-17	



ID	Part No.	Description
1	SY125-I-1	REAR SHOCK ASSEMBLY
2	SY125-I-2	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
3	SY125-I-3	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
4	SY125-I-4	HEXAGON FLANGE NYLON LOVK NUT
5	SY125-I-5	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
6	SY125-I-6	FRONT SHOCK ASSEMBLY



ID	Part No.	Description
1	SY125-J-1	HANDLEBAR SLEEVE
2	SY125-J-2	REAR LARGE SINGLE DISC BRAKE ASSEMBLY
3	SY125-J-3	THROTTLE CABLE
4	SY125-J-4	REAR DISC BRAKE OIL HOSE CLIP
5	SY125-J-5	INNER HEXAGON HALF SOCKET SCREW GB70.2
6	SY125-J-6	STEEL STEERING HANDLEBAR
7	SY125-J-7	FRONT LARGE SINGLE DISC BRAKE ASSEMBLY
8	SY125-J-8	SINGLE THUMBER OILER
9	SY125-J-9	SPRING WASHER
10	SY125-J-10	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
11	SY125-J-11	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
12	SY125-J-12	HEXAGON FLANGE SELF-LOCKING NUTS GB6187-86
13	SY125-J-13	EMERGENCY EXTINGUISHING SWITCH
14	SY125-J-14	ROUND SHEATH CORE
15	SY125-J-15	SHEATH LEATHER
16	SY125-J-16	REAR BRAKE OIL PIPE SEAT
17	SY125-J-17	INNER HEXAGON SOCKET HEAD SCREW GB70-85



ID	Part No.	Description
----	----------	-------------

	ID	Part No.	Description
	1	SY125-K-1	FRONT WHEEL TIRE
	2	SY125-K-2	DUST CAP
	3	SY125-K-3	FRONT WHEEL RIM
	4	SY125-K-4	FRONT DISC BRAKE FLANGE SEAT
	6	SY125-K-6	FRONT HUB TRIM CAP
	7	SY125-K-7	CROSS COUNTERSUNK HEAD MANCHINE SCREW GB819
	8	SY125-K-8	FRONT DISC BRAKE

	ID	Part No.	Description
	1	SY125-L-1	REAR WHEEL TIRE
	2	SY125-L-2	DUST CAP
	3	SY125-L-3	REAR WHEEL RIM
	4	SY125-L-4	REAR WHEEL HUB FLANGE
	5	SY125-L-5	EXTERNAL HEXAGON SMALL HEAD FLANGE BOLTS GB5787
	6	SY125-L-6TEAL	REAR HUB TRIM CAP(teal)
		SY125-L-6RED	REAR HUB TRIM CAP(RED)

	ID	Part No.	Description
	1	SY125-M-1	BATTERY
	2	SY125-M-2	BATTERY TYPE
	3	SY125-M-3	IGNITION COIL
	4	SY125-M-4	EXTERNAL HEXAGON BIG HEAD FLANGE BOLTS GB5787
	4-1	SY125-M-4-1	
	5	SY125-M-5	RECTIFIER
	6	SY125-M-6	FUNCTION SWITCH
	7	SY125-M-7	CDI
	8	SY125-M-8	LEFT HEADLIGHT
	9	SY125-M-9	RIGHT HEADLIGHT
	10	SY125-M-10	REAR TAILGHT
	11	SY125-M-11	MAIN CABLE ASSEMBLY
	12	SY125-M-12	ELECTRIC LOCK
	13	SY125-M-13	RUBBER HARNESS BINDING
	14	SY125-M-14	CROSS PAN HEAD TAPPING SCREWS GB845-85
	15	SY125-M-15	GEAR DISPLAY
	15-1	SY125-M-15-1	GEAR DIAPLAY COVER
	16	SY125-M-16	RELAY
	17	SY125-M-17	HEXAGON FLANGE TOOTHED NUT GB6177-86
18	SY125-M-18	HEXAGON FLANGE NYLON LOCK NUT	
19	SY125-M-19	THROTTLE CABLE	

	ID	Part No.	Description
	1	SY125-N-1BLK	REAR PLASTIC KIT(Black)
		SY125-N-1GRY	REAR PLASTIC KIT(Grey)
	2	SY125-N-2BLK	FRONT PLASTIC KIT
		SY125-N-2GRY	FRONT PLASTIC KIT
	3	SY125-N-3	FRONT HOOD
	3-1	SY125-N-3-1	MACHINE SCREW CARD
	4	SY125-N-4	FRONT COVER
	5	SY125-N-5	LEFT HEADLIGHT HOOD
	6	SY125-N-6	RIGHT HEADLIGHT HOOD
	7	SY125-N-7	LEFT FOOT
8	SY125-N-8	RIGHT FOOT	
9	SY125-N-9	INNER HEXAGON BIG PAN HEAD BOLT	
10	SY125-N-10	RUBBER FLAT PAD	

