



MZ50-M5

Parts No.	Discription	Qty per Vehicel
PMZ50-M5-A-001	Muffer	1
PMZ50-M5-A-002	Pipe	1
PMZ50-M5-A-003	Rear brake line	1
PMZ50-M5-A-004	Rear Shock Absorber Assy	1
PMZ50-M5-A-005	Seat Cable	1
PMZ50-M5-A-006	Gasket on muffer	1
PMZ50-M5-A-007	Clamp buffer skin	2
PMZ50-M5-A-008	Muffer clamp	2

PMZ50-M5-B-001	Frame	1

PMZ50-M5-C-001	Handbar	1
PMZ50-M5-C-002	Rear fender bracket	1

PMZ50-M5-C-003	Headlight Bracket	1
PMZ50-M5-C-004	Rear Shock Absorber bracket (L)	1
PMZ50-M5-C-005	Rear Shock Absorber bracket (R)	1
PMZ50-M5-C-006	Engine Mount	1
PMZ50-M5-C-007	Rear Brake Lever	1
PMZ50-M5-C-008	Kick Stand	1
PMZ50-M5-C-009	Electric lock bracket	1
PMZ50-M5-C-010	Kick Stand spring	1
PMZ50-M5-C-011	Tachometer cable clip	1
PMZ50-M5-C-012	Disc brake cable clip	1




PMZ50-M5-D-001	Fuel Tank	1
PMZ50-M5-D-002	Fuel-level Sensor	1
PMZ50-M5-D-003	Fuel-level Sensor sealing ring	1
PMZ50-M5-D-004	Rear brake cable cover	1
PMZ50-M5-D-005	Rubber cushion under fuel	2
PMZ50-M5-D-006	Headlight Rubber Cushion	2
PMZ50-M5-D-007	Speedometer Rubber Cushion	3
PMZ50-M5-D-008	Rubber cushion behind fuel tank	2
PMZ50-M5-D-009	Rubber cushion front fuel tank	1
PMZ50-M5-D-010	Rubber cushion inner bushing of Tailight	2
PMZ50-M5-D-011	Rubber cushion of Tailight	2
PMZ50-M5-D-012	Rubber cushion bushing under fuel	2
PMZ50-M5-D-013	Headlight bracket rubber cushion	4



PMZ50-M5-E-001	L.Foot rest Assy	1
PMZ50-M5-E-002	R.Foot rest Assy	1
PMZ50-M5-E-003	Front Shock Absorber	2
PMZ50-M5-E-004	Front brake	1
PMZ50-M5-E-005	Steering stem	1
PMZ50-M5-E-006	Steel bowl	9
PMZ50-M5-E-007		
PMZ50-M5-E-008	Tachometer	1
PMZ50-M5-E-009	Front axle	1
PMZ50-M5-E-010	front axle bushing	1



PMZ50-M5-F-001	Front tire 120/70-12	1
PMZ50-M5-F-002	Rear tire 130/70-12	1
PMZ50-M5-F-003	Rear Hub	1
PMZ50-M5-F-004	Front Hub	1
PMZ50-M5-F-005	Front brake disc	1
PMZ50-M5-F-006	Front brake disc screw bolt	4
PMZ50-M5-F-007	Tubeless valve	2




PMZ50-M5-G-001	Engine	1
PMZ50-M5-G-002	Engine Hanger	1
PMZ50-M5-G-003	Air Filter	2
PMZ50-M5-G-004	Carburetor	1
PMZ50-M5-G-005	Throttle cable	4
PMZ50-M5-G-006	Bushing	2
PMZ50-M5-G-007	Air filter clamp	1
PMZ50-M5-G-008	Outer bushing	1
PMZ50-M5-G-009	Inner bushing	1
PMZ50-M5-G-010	Nut	1



PMZ50-M5-H-001	Headlight	1
PMZ50-M5-H-002	Rear light	1
PMZ50-M5-H-003	Speedometer	1
PMZ50-M5-H-004	Left hand grip	1

PMZ50-M5-H-005	Throttle grip	1
PMZ50-M5-H-006	Left control panel	1
PMZ50-M5-H-007	Right control panel	1
PMZ50-M5-H-008	Rear left turning light	1
PMZ50-M5-H-009	Rear right turning light	1
PMZ50-M5-H-010	Rear Reflector	1
PMZ50-M5-H-011	Rear license plate light	1
PMZ50-M5-H-012	Front left turning light	1
PMZ50-M5-H-013	Front right turning light	1



PMZ50-M5-I-001	Main wire	1
PMZ50-M5-I-002	Ignition coil	1
PMZ50-M5-I-003	Starter relay	1
PMZ50-M5-I-004	Relay assy,tunsignal	1
PMZ50-M5-I-005	CDI	1
PMZ50-M5-I-006	Regulator	1
PMZ50-M5-I-007	Horn	1
PMZ50-M5-I-008	Seat cushion lock	1
PMZ50-M5-I-009	Ignition switch lock	1
PMZ50-M5-I-010	Seat lock	1
PMZ50-M5-I-011	Seat Cushion Lock Cable Bracket	1
PMZ50-M5-I-012	Fuel Tank Cap	1
PMZ50-M5-I-013	Seat Cushion Lock Buckle	1
PMZ50-M5-I-014	Key	1



PMZ50-M5-J-001	Seat	1
PMZ50-M5-J-002	Left rear mirror	1
PMZ50-M5-J-003	Right rear mirror	1
PMZ50-M5-J-004	Handle bar block	2
PMZ50-M5-J-005	HANDLEBAR HOLDER	2
PMZ50-M5-J-006	Rubber cussion of handle bar block	4



PMZ50-M5-K-001	Left Decorating plate of Right side	1
PMZ50-M5-K-002	Right Decorating plate of Right side	1
PMZ50-M5-K-003	Front part of front fender	1
PMZ50-M5-K-004	Battery box	1
PMZ50-M5-K-005	Small Rear Fender	1
PMZ50-M5-K-006	Rear part of front fender	1
PMZ50-M5-K-007	Speedometer cover	1
PMZ50-M5-K-008	Decorating Panel of front Shock Absorber (L)	1
PMZ50-M5-K-009	Decorating Panel of front Shock Absorber (R)	1




PMZ50-M5-L-001	Front fender	1
PMZ50-M5-L-002	Fuel tank cap outer cover	1
PMZ50-M5-L-003	Rear fender	1
PMZ50-M5-L-004	Rear Fender bottom cover	1
PMZ50-M5-L-005	Headlight Cover	1
PMZ50-M5-L-006	Fuel tank cap inner cover	1



PMZ50-M5-M-001	Cover of Battery Box (L)	1
PMZ50-M5-M-002	Cover of Battery Box (R)	1
PMZ50-M5-M-003	Decorating Panel of Left cover	1
PMZ50-M5-M-004	Decorating Panel of Right cover	1
PMZ50-M5-M-005	Left side cover front connect plate	1

PMZ50-M5-M-006	Right side cover front connect plate	1
PMZ50-M5-M-007	Right side cover bottom connect plate	1
PMZ50-M5-M-008	Left side cover bottom connect plate	1
PMZ50-M5-M-009	Seat Lock's Box	1



PMZ50-M5-N-001	Side Cover(L)	1
PMZ50-M5-N-002	Side Cover(R)	1
PMZ50-M5-N-003	Decorating Panel of Battery Box(L)	1
PMZ50-M5-N-004	Decorating Panel of Battery Box(R)	1
PMZ50-M5-N-005	Left Taillight cover	1
PMZ50-M5-N-006	Right Taillight cover	1
PMZ50-M5-N-007	Left connect plate on Battery box	1
PMZ50-M5-N-008	Right connect plate on Battery box	1
PMZ50-M5-N-009	F. Right Turning light Bracket	1
PMZ50-M5-N-010	F. Left Turning light Bracket	1
PMZ50-M5-N-011	Taillight cover	1
PMZ50-M5-N-012	Seat Lock's cover (R)	1
PMZ50-M5-N-013	Seat Lock's cover (L)	1