



Rear Fender & Tail Light Assembly




Parts No.	Description	Qty per Vehicle
PMZ50-4-A-001	Rear Fender	1
PMZ50-4-A-002	Rear Light Assy	1
PMZ50-4-A-003	Rear Retro Reflecting Device	1
PMZ50-4-A-004	Side Circular Reflecting Device	2
PMZ50-4-A-005	Bracket,Registration Plate	1
PMZ50-4-A-006	Rear Mudguard, Rear Wheel	1

Toolbox & Foot Rest Assembly




Parts No.	Description	Qty per Vehicle
PMZ50-4-B-001	Cover, Battery	1
PMZ50-4-B-002	Footrest Base Panel	1
PMZ50-4-B-003	Lower, Front Luggage Carrier	1
PMZ50-4-B-004	USB	1
PMZ50-4-B-005	Helmet Hook	1
PMZ50-4-B-006	Box, Battery	1
PMZ50-4-B-007	Fender	1
PMZ50-4-B-008	Upper, Front Luggage Carrier	1
PMZ50-4-B-009	Cover, Chassis No.	1
PMZ50-4-B-010	Rubber Mat	1
PMZ50-4-B-011	Hook, seat cask	1




Parts No.	Description	Qty per Vehicle
PMZ50-4-C-001	Right Shield	1
PMZ50-4-C-002	Front cover, seat	1
PMZ50-4-C-003	R. Decorating Cover	1
PMZ50-4-C-004	Rear Central Decorating Cover	1
PMZ50-4-C-005	Rear Shield	1
PMZ50-4-C-006	L. Decorating Cover	1
PMZ50-4-C-007	Left Shield	1



Parts No.	Description	Qty per Vehicle
PMZ50-4-D-001	Inside Cover, seat bucket	1
PMZ50-4-D-002	Seat bucket	1
PMZ50-4-D-003	SEAT CUSION LOCK HOOK	1
PMZ50-4-D-004	Rear rack	1
PMZ50-4-D-005	seat	1
PMZ50-4-D-006	Lock Assy, Seat	1
PMZ50-4-D-007	Cable, Seat Lock	1
PMZ50-4-D-008	rack Plug 1.5,	3



Parts No.	Description	Qty per Vehicel
PMZ50-4-E-001	Side Circular Reflecting Device	1
PMZ50-4-E-002	Rear front fender	1
PMZ50-4-E-003	Front rear fender	1
PMZ50-4-E-004	Rear single shock 250 black	1
PMZ50-4-E-005	Lower Bridge Assy, Steer Stem	1
PMZ50-4-E-006	Front shock	1
PMZ50-4-E-007	Bottom Concave, Steel Ball Bowl Assy	1
PMZ50-4-E-008	Top Protrude, Steel Ball Bowl Assy	
PMZ50-4-E-009	Flange Lock Nut	1
PMZ50-4-E-010	Dust boot for Steel bowl,	1
PMZ50-4-E-011	Upper bush, rear shock	1
PMZ50-4-E-012	Upper bush's buffer, rear shock	1
PMZ50-4-E-013	Speed counter	1
PMZ50-4-E-014	Cable, Odometer	1



Parts No.	Description	Qty per Vehicel
PMZ50-4-F-001	Brake Switch RH	1
PMZ50-4-F-002	Brake Switch LH	1
PMZ50-4-F-003	Left Lever	1
PMZ50-4-F-004	Right Lever	1
PMZ50-4-F-005	Brake upper Pump (master cylinder)	1
PMZ50-4-F-006	Pump Bracket (caliper mounting bracket) (sold as assembly)	1
PMZ50-4-F-007	Brake under the Pump (caliper)	1
PMZ50-4-F-008	Brake pad	1
PMZ50-4-F-009	Brake clip (sold as assembly)	1
PMZ50-4-F-010	Cable Bracket (sold as assembly)	1
PMZ50-4-F-011	Brake Cable Clip (sold as assembly)	1
PMZ50-4-F-012	Brake tube	1
PMZ50-4-F-013	Bottom Bracket pin (sold as assembly)	2
PMZ50-4-F-014	Oil bolts (sold as assembly)	2
PMZ50-4-F-015	Seal spacer (sold as assembly)	2
PMZ50-4-F-016	Brake upper Pump Cap (sold as assembly)	1

--	--	--



Parts No.	Description	Qty per Vehicel
PMZ50-4-G-001	Throttle Cable	1
PMZ50-4-G-002	Multi-function switch(left)	1
PMZ50-4-G-003	Cable for left turn light	1
PMZ50-4-G-004	Bracket for turn lights	1
PMZ50-4-G-005	Meter	1
PMZ50-4-G-006	Meter Cover	1
PMZ50-4-G-007	Grip(left)	1
	Grip(right)	1
PMZ50-4-G-008	Handle Comp	1
PMZ50-4-G-009	Headlight cover	1
PMZ50-4-G-010	Brake line	1
PMZ50-4-G-011	Multi-function switch(right)	1
PMZ50-4-G-012	Cable for left turn light	1
PMZ50-4-G-013	Rear View Mirror, L./R	1




Parts No.	Description	Qty per Vehicel
PMZ50-4-H-001	Kenda tire	1
PMZ50-4-H-002	Front rim	1
PMZ50-4-H-003	disc	1
PMZ50-4-H-004	Tubeless Valve	1
PMZ50-4-H-005	Front axle bushing 12*13	1
PMZ50-4-H-006	Front wheel inner tube	1
PMZ50-4-H-007	Axle 10*198	1

PMZ50-4-H-008	Bearing 6201	2
PMZ50-4-H-009	Bolts M8*25	3




Parts No.	Description	Qty per Vehicel
PMZ50-4-J-001	Kenda tire	1
PMZ50-4-J-002	Rear rim	1
PMZ50-4-J-003	Tubeless Valve	1



Parts No.	Description	Qty per Vehicel
PMZ50-4-K-001	Circular Sensors	1
PMZ50-4-K-002	Fuel Tank Assy	1
PMZ50-4-K-003	Breather Tube	1
PMZ50-4-K-004	Breather Tube	1
PMZ50-4-K-005	Overflow Oil Tube	1
PMZ50-4-K-006	Gearbox, exhause pipe clip	1
PMZ50-4-K-007	Oil switch	1
PMZ50-4-K-008	Fuel Filter	1
PMZ50-4-K-009	Clip 7#	6
PMZ50-4-K-010	Clip 8#	8






Parts No.	Description	Qty per Vehicle
PMZ50-4-L-001	Carburetor Assy	1
PMZ50-4-L-002	Body, Air Cleaner	1
PMZ50-4-L-003	Cover, Air Ceaner	1
PMZ50-4-L-004	filter	1
PMZ50-4-L-005	Air filter plug	1
PMZ50-4-L-006	Engine Assy	1



Parts No.	Description	Qty per Vehicle
PMZ50-4-M-001	Exhaust Muffler	1
PMZ50-4-M-002	Muffler cover	1
PMZ50-4-M-003	Muffler gasket	1






Parts No.	Description	Qty per Vehicle
PMZ50-4-N-001	Main Stand Assy	1
PMZ50-4-N-002	Side Stand Assy	1
PMZ50-4-N-003	Buffer of hanger	1
PMZ50-4-N-004	Main stand spring	1
PMZ50-4-N-005	Side Stand Spring(internal circlip)	1
PMZ50-4-N-006	Side Stand Spring(external circlip)	1




Parts No.	Description	Qty per Vehicle
PMZ50-4-P-001	Battery assy	1



Parts No.	Description	Qty per Vehicle
PMZ50-4-Q-001	Wire Harness	1

PMZ50-4-Q-002	Ignition Coil Assy	1
PMZ50-4-Q-003	Rectifier	1
PMZ50-4-Q-004	Relay	1
PMZ50-4-Q-005	Horn	1
PMZ50-4-Q-006	Winker Relay	1
PMZ50-4-Q-007	ignition	1
PMZ50-4-Q-008	Strip Set	5






Parts No.	Description	Qty per Vehicel
PMZ50-4-R-001	Frame	1
PMZ50-4-R-002	Bracket, Front Mudguard	1
PMZ50-4-R-003	Bracket, Lock Assy, Seat	1
PMZ50-4-R-004	Block Holder, Fuel Tank	1
PMZ50-4-R-005	Hanger liner	1
PMZ50-4-R-006	Block Holder, Fuel Tank, pull block	1
PMZ50-4-R-007	Retainer Rubber, Swing arm	1
PMZ50-4-R-008	Block Holder, Fuel Tank, left lever	1
PMZ50-4-R-008-01	Block Holder, Fuel Tank, right lever	1
PMZ50-4-R-009	Left Shield	1
PMZ50-4-R-009-01	Right Shield	1
PMZ50-4-R-010	Bracket, Horn	1
PMZ50-4-R-011	Swing arm	1
PMZ50-4-R-012	Lock Set with cable	1



Parts No.	Description	Qty per Vehicel
PMZ50-4-S-001	L. Front Turning Light Assy	1
PMZ50-4-S-002	Headlight Assy	1
PMZ50-4-S-003	R. Front Turning Light Assy	1
PMZ50-4-S-004	Front Shield light	1
PMZ50-4-S-005	Decorating Small Cover, Front Cover	1
PMZ50-4-S-006	Front Cover	1
PMZ50-4-S-007	Front Shield	1





<div><div><div>1</div></div><div><div>2</div></div><div><div>3</div></div></div>		
<b>Parts No.</b>	<b>Description</b>	<b>Qty per Vehicel</b>
PMZ50-4-T-001	Owner's manual	1
PMZ50-4-T-002	Tools Bag	1
PMZ50-4-T-003	Spark Plug Socket	1
	Double Ended Spanne	1
	Screw Driver	1